




66402 Tool Post Grinder Instruction Manual


Air Powered Abrasive Belt Machine

⚠ WARNING

Always operate, inspect and maintain this tool in accordance with the Safety Code for portable air tools (ANSI B186.1) and any other applicable safety codes and regulations. Please refer to Dynabrade's Warning/Safety Operating Instructions for more complete safety information.



66402 Tool Post Grinder-Machine Parts Breakdown



Index Key	
No.	Part # Description
1	66440 Air Motor
2	66435 O-Ring
3	97565 Thrust Washer
4	97813 Seal
5	66413 Spacer
6	66412 Drive Wheel
7	95314 Knob
8	97152 Cap Screw (5)
9	65132 Tracking Hub
10	95417 Washer
11	95186 Nut
12	66419 Tracking Shaft
13	66427 Ported Screw
14	95740 Air Control Stem
15	95526 O-Ring (2)
16	66427 Manifold
17	95525 Retaining Ring
18	97896 Close Nipple
19	97894-B Valve Assembly
20	97435 Silencer
21	97828 Elbow Fitting
22	97829 Tubing (6 in.)
23	97894-c Regulator Assembly
24	95696 Gage
25	66421 Rear Housing
26	97050 Cap Screw (6)
27	97550 Bushing (2)
28	97108 Set Screw (2)
29	01025 O-Ring (2)
30	66418 Motor Lock (2)
31	97069 Carriage Screw
32	97805 Cylinder
33	66424 Pin
34	66423 Extension Block
35	97772 Spring Clip
36	66422 Cover
37	97733 Knob
38	97889 Breather Vent
39	97112 Set Screw (2)
40	66420 Front Housing
41	97083 Cap Screw (4)
42	66416 Mount
43	97058 Cap Screw (2)
44	66425 Vacuum Scoop
45	66417 Contact Wheel Shaft
46	66430 Contact Wheel
47	97516 Bearing
48	97435 Retaining Ring
49	66434 O-Ring

Machine Number	Length Inch (mm)	Width Inch (mm)	Height Inch (mm)	Machine Weight	Abrasive Belt Size	Air Inlet Thread	Hose Size	Air Pressure	Motor RPM	SFPM	SCFM Required
66402	13 5/8" (345)	9 3/4" (248)	9 3/8" (238)	19 lbs. (8.60 kg)	1-1/2" W x 24" L	3/8" NPT	1/2"	90 PSI	7,200	4,700	47

66440 Air Motor


Key

- O** Oil: O_1 = Air Lube
- G** Grease: G_1 = Lubriplate 630 AA
- A** Adhesive: A_2 = Loctite #271
 A_8 = Loctite #567
- T** Torque: $N \cdot m \times 8.85 = In. - lbs.$

Index Key

No. Part # Description

1	52164	Exhaust Cover
2	52166	Seal
3	94522	Muffler Cap
4	95375	O-Ring
5	50511	Screw (2)
6	01791	Split Lock Washer (3)
7	52180	Exhaust Clamp
8	52161	Gasket
9	66442	Housing Assembly
10	01823	Washer
11	96151	Shim
12	96152	Shim (2)
13	01036	Bearing
14	52476	Rear End Plate
15	01672	Spring Pin
16	52475	Cylinder
17	52474	Rotor Blade (4/pkg.)
18	52466	Rotor
19	52467	Rotor Spacer
20	52472	Front End Plate
21	52469	Shim
22	52470	Shim
23	01825	Bearing
24	01815	Spindle Nut
25	52478	Governor Cage
26	52498	Governor Weight (2)
27	96059	Grooved Pin (2)
28	50468	Pin
29	50541	2.0Hp Governor Valve
30	52174	Shim (2)
31	52175	Shim (2)
32	01829	Spring
33	50548	Spring Holder
34	52477	Gasket
35	52461	Governor Cover
36	95720	Screw (4)



66440 Air Motor Disassembly/Assembly Instructions

Important: Manufacturers warranty is void if tool is disassembled before warranty expires.

To Disassemble:

1. Disconnect power source from machine.
2. Remove machine from lathe mount and remove abrasive belt. Loosen **97108** Set Screws (2) on machine housing
3. Slide **66440** Air Motor from machine housing.
4. Remove drive wheel by inserting a 1/4" Hex Wrench into end of rotor shaft and twist drive wheel from motor.
5. Remove **66413** Spacer and **97813** Seal from rotor shaft.
6. Secure motor housing in padded vise with housing cover facing upwards.
7. Remove **95720** Screws (4) and **01791** Washers and lift off cover.
8. Remove motor assembly from motor housing.
9. Remove governor cage assembly (left handed threads).
10. Press **52466** Rotor from **52476** Bearing Plate and **01036** Bearing. Press bearing from bearing plate.
11. Remove cylinder and rotor blades. Secure rotor in vise and remove rotor nut.
12. Remove **52472** Bearing Plate from rotor. Press **52469** & **52470** Shims and **01825** Bearing from bearing plate.

To Reassemble:

Important: Be certain parts are clean and in good repair before reassembling.

1. Install **52469** & **52470** Shims into **52472** Bearing Plate so they seat flush.
2. Press in **01825** Bearing. Install assembly on to rotor shaft.

(continued on page 4)

66440 Air Motor Disassembly/Assembly Instructions (continued)

3. Install rotor nut (with wrench flats towards rotor) onto rotor shaft (torque 250 In-lbs.).
4. Check clearance between rotor and bearing plate. Clearance should not exceed .002".
5. Press **01036** Bearing into **52476** Bearing Plate.
6. Install blades and cylinder onto rotor. Make sure air inlet holes in cylinder line up with air inlet holes in bearing plate.
7. Press **52476** Bearing Plate and bearing onto rotor. Line up pin holes and air inlet holes.
8. Check rotation of rotor. Rotor should turn freely and the cylinder walls should be flush with bearing plate edges.
9. Install governor cage assembly onto rotor (left hand threads). Torque 80 In-lbs.
10. Insert motor assembly into motor housing. Line up **01673** Pin in bearing plate with pin slot in motor housing.
11. Replace gasket and housing cover and secure with **95720** Screws (4) and **01791** Washers (torque 80 In-lbs.).
12. Replace **66413** Spacer and **97813** Seal onto rotor shaft (suction cup end of **97813** Seal should face motor housing).
13. Replace drive wheel.
14. Insert motor into machine housing.
15. Tighten **97108** Set Screws (2) to lock motor in position.

Reassembly is complete. Check motor RPM with a tachometer. If motor is opening at a higher RPM than marked on the tool, then the tool should be serviced to correct the cause before use. Before operating we recommend that 3-4 drops of air tool oil be placed directly into the air inlet. Operate tool for approximately 30 seconds prior to application to work piece to determine if tool is operating properly and safely and to allow lubricating oils to thoroughly penetrate tool.


Mounting and Machine Adjustment Instructions

Turning Passes (Standard Mounting):

1. Install machine, using **66416** Key Mount, into standard cutting tool holder on lathe and tighten.
2. Position tool holder so contact wheel of machine is at or slightly above work piece centerline.
3. Adjust angle of contact wheel, using a dial indicator (not included), so face of contact wheel is parallel to lathe center line.

Important: Abrasive belt cannot be on tool during this procedure.

4. Install abrasive belt on tool (see "Abrasive Belt Change/Installation").
5. Begin operating procedures.




Facing Passes (optional 66439 Key Mount must be used):

1. Install **66439** Key Mount to back of **66420** Front Housing with the four (4) screws supplied with mount. Key of **66420** Mount should face forward.
2. Install machine offset 90 degrees from standard mount into cutting tool holder
3. Position tool holder so contact wheel of machine is at or slightly above work piece centerline.
4. Adjust angle of contact wheel using a dial indicator (not included) so face of contact wheel is perpendicular to lathe center line.


Important: Abrasive belt cannot be on tool during this procedure.

5. Install Abrasive belt on tool (see "Abrasive Belt Change/Installation")
6. Begin operating procedures.



Abrasive Belt Change/Installation:

1. Turn air control valves on air regulator and 66411 Manifold to off positions.
2. Disconnect power source from machine.
3. Remove **66422** Cover and position belt over drive wheel and contact wheel.
4. Replace **66422** Cover.
5. Turn **97894-B** Air Valve on air tension assembly to open position and adjust belt tensions to 60 PSI by turning **97894-C** Regulator to right or left accordingly.
Note: Always adjust air pressure up to set point, never adjust down.
6. Adjust belt tracking (see "Belt Tracking Adjustment").



Belt Tracking Adjustment:

1. With abrasive belt installed and belt tension set, turn **95740** Air Control Stem on manifold to the open position. Abrasive belt will begin rotation.
2. Adjust belt tracking by turning the **95314** Knob to the left or right accordingly so the belt rides evenly over contact wheel.

Important Operating, Maintenance and Safety Instructions

Carefully read all instructions before operating or servicing any Dynabrade® Abrasive Power Tool.

Important: All Dynabrade air tools must be used with a Filter-Regulator-Lubricator to maintain all warranties.

Operating Instructions:



Warning: Eye, face, respiratory, sound, and body protection must be worn while operating power tools. Failure to do so may result in serious injury or death. Follow safety procedures posted in workplace.

1. With power source disconnected from tool, securely fasten tool to lathe (see Mounting and Machine Adjustment Instructions, page 3).
2. Install Abrasive Belt on tool (see Abrasive Belt Change/Installation Instructions, page 3).
3. Operate machine for 30 seconds prior to application to work piece to determine if machine is working properly and safely before work begins.

Maintenance Instructions:

Products offered by Dynabrade should not be converted or otherwise altered from original design without the expressed written consent from Dynabrade, Inc..

1. Check tool speed with tachometer. If tool is operating at a higher speed than the RPM marked on the tool or operating improperly, the tool should be serviced to correct the cause before use.
2. Some silencers on air tools may clog with use. Clean and replace as required.
3. All Dynabrade air motors should be lubricated with two drops of Dynabrade Air Lube (P/N **95842**: 1pt. 473ml.) every four hours of use.
4. An Air Line Filter-Regulator-Lubricator must be used with this air tool to maintain all warranties. Dynabrade recommends the following: **11299** Air Line Filter-Regulator-Lubricator — Provides accurate air pressure regulation, two-stage filtration of water contaminants and positive-drip lubrication of pneumatic components. Operates 100 SCFM @ 100 PSI has 1/2" NPT female ports.
5. Good house keeping is essential to insure long life of any machine tool. By keeping machine clean and visually inspected for any wear, the machine will provide many years of quality service. Repair or replacement of worn parts early enough will prevent other parts from becoming damaged.

Safety Instructions:

Products offered by Dynabrade should not be converted or otherwise altered from original design without expressed written consent from Dynabrade, Inc.



- **Important:** User of tool is responsible for following accepted safety codes such as those published by the American National Standards Institute
- Operate machine for 30 seconds before application to workpiece to determine if machine is working properly and safely before work begins.
- Always disconnect power supply before changing abrasive or making machine adjustments.
- Inspect abrasives and accessories for damage or defects prior to and during operation of tool.
- Please refer to Dynabrade's Warning/Safety Operating Instructions Tag (Reorder No. **95903**) for more complete safety information.
- Never use an abrasive belt that is narrower than the contact wheel. The uncovered wheel face can cause snagging of workpiece and also cause premature wear of contact wheel.
- Always use an upward stroke of the workpiece against the abrasive belt and use the grind area below the center line of the contact wheel.
- **Warning:** There is a potential combustion hazard if ferrous and non-ferrous grinding dust is mixed. Do not grind materials of different types without thoroughly cleaning grinding residue from inside the machine.

Notice

All Dynabrade motors use the highest quality parts and metals available and are machined to exacting tolerances. The failure of quality pneumatic motors can most often be traced to an unclean air supply or the lack of lubrication. Air pressure easily forces dirt or water contained in the air supply into motor bearings causing early failure. It often scores the cylinder walls and the rotor blades resulting in limited efficiency and power. Our warranty obligation is contingent upon proper use of our tools and cannot apply to equipment which has been subjected to misuse such as unclean air, wet air or a lack of lubrication during the use of this tool.


Note: To order replacement parts specify the model and serial number of your machine.

Full One Year Warranty

Following the reasonable assumption that any inherent defect which might prevail in a product will become apparent to the user within one year from the date of purchase, all equipment of our manufacture is warranted against defects in workmanship and materials under normal use and service. We shall repair or replace at our factory, any equipment or part thereof which shall, within one year after delivery to the original purchaser, indicate upon our examination to have been defective. Our obligation is contingent upon proper use of Dynabrade tools in accordance with factory recommendations, instructions and safety practices. It shall not apply to equipment which has been subject to misuse, negligence, accident or tampering in any way so as to affect its normal performance. Normally wearable parts such as bearings, contact wheels, rotor blades, etc., are not covered under this warranty.

Contact Wheel Assembly

Contact Wheel Assembly Parts (sold separately)



Contact Wheel Change:

1. Turn air control valves to closed position. Disconnect power source from tool.
2. Remove belt from tool.
3. Remove **97112** Set Screw from front housing and remove entire contact wheel assembly.
4. Remove **97435** Retaining Ring.
5. Press **66417** Contact Wheel Shaft from contact wheel and bearing.
6. Press new contact wheel, with bearing installed, onto contact wheel shaft.
7. Line up recess hole in contact wheel shaft with set screw hole in front housing. Replace and tighten set screw with shoulder of contact wheel shaft pressed firmly against machine face of front housing.

Accessories

95800 Hose Cuff 1-1/4" x 1-1/4" (32mm x 32mm) Dia.

Has internal thread for 1-1/4" (32mm) dia. hose.  Mounts to machine's vacuum scoop.

One cuff (not installed). Mounts directly to machine.


54205 Exhaust Hose 1-1/4" (32mm) Diameter



By-the-foot (no cuffs); specify up to 50 feet (15 meters).

66438 Coolant Nozzle Assembly

For wet operations.



Controls flow and splash point of coolant.

66439 Key Mount



66439 Mount

Allows offset tool installation for "facing" passes.

Precision Tool Post Grinder Contact Wheels

Part No.	Diameter	Width	Face Material
66429	4"	1-1/2"	50 Duro Plain Neoprene
66430	4"	1-1/2"	70 Duro Plain Neoprene
66431	4"	1-1/2"	90 Duro Plain Neoprene
66432	4"	1-1/2"	70 Duro Serrated Neoprene
66433	4"	1-1/2"	90 Duro Serrated Neoprene



96259 Motor Tune-Up Kit:

Includes assorted parts to help maintain motor in tip-top shape.

Visit our Web Site: www.dynabrade.com

Email: Customer.Service@Dynabrade.com



DYNABRADE, INC., 8989 Sheridan Drive • Clarence, NY 14031-1490 • Phone: (716) 631-0100 • Fax: 716-631-2073 • International Fax: 716-631-2524
DYNABRADE EUROPE S.à.r.l., Zone Artisanale • L-5485 Wormeldange—Haut, Luxembourg • Telephone: 352 76 84 94 1 • Fax: 352 76 84 95 1

© DYNABRADE, INC., 2000

PRINTED IN USA