


Dynascaler®

Model:
30336

Machine and Motor Parts

⚠ WARNING

Always operate, inspect and maintain this tool in accordance with the Safety Code for portable air tools (ANSI B186.1) and any other applicable safety codes and regulations. Please refer to Dynabrade's Warning/Safety Operating Instructions for more complete safety information.



*See page 2 for Motor Assembly and Important Operating, Maintenance and Safety Instructions.

Dynascaler® Air Motor – 04004

