


Dynabelter®

Model: 11477

2" Wide Abrasive Belt Capacity


⚠ WARNING

Always operate, inspect and maintain this tool in accordance with the Safety Code for portable air tools (ANSI B186.1) and any other applicable safety codes and regulations. Please refer to Dynabrade's Warning/Safety Operating Instructions for more complete safety information.



Includes: 11705 Pressure Bar Assembly (shown above).
11870 Contact Arm Assembly (shown above).
95048 1/8" Hex Wrench. For adjusting motor position.
95049 3/16" Hex Wrench. For removing/installing 11705 Pressure Bar Assembly.

01800 Air Motor (Includes 01794 Drive Wheel)



IMPORTANT: ALL DYNABRADE AIR TOOLS MUST BE USED WITH A FILTER-REGULATOR-LUBRICATOR TO MAINTAIN ALL WARRANTIES

IMPORTANT

- Tool RPM rating must never exceed abrasive/accessory RPM rating, regardless of the tool's capacity.
- Check tool speed regularly with a tachometer. If tool is operating at a higher speed than the RPM marked on the tool, the tool should be serviced to correct the cause of this situation before use.
- 11299 Air Line Filter-Regulator-Lubricator — Provides accurate air pressure regulation, two-stage filtration of water contaminants and micro-mist lubrication of pneumatic components; operates to 100 CFM @ 90 PSI; has 1/2" female ports.

Note: To order replacement parts specify the model and serial number of your machine.

Warning: Hand, wrist and arm injury may result from repetitive work motion and overexposure to vibration.



DYNABRADE, INC., 8989 Sheridan Drive • Clarence, New York 14031-1490 • Phone: (716) 631-0100 • Fax: 716-631-2073 • Telex: 646540
DYNABRADE EUROPE s.a.r.l., Zone Artisanale • L-5485 Wormeldange-Haut, Luxembourg • Telephone: 352 76 84 94 • Fax: 352 76 84 95